

## Uputstva za demontažu izvora svjetlosti i predspojene naprave

### Primjenjivo na: USP

- 1) Izbaciti sklopku iz funkcije kako svjetiljka ne bi bila pod naponom prilikom demontaže.
  - 2) Pažljivo povlačiti aluminijski raster tako da iskoči do dijela gdje su vidljive njegove noseće opruge.
  - 3) Pritiskom na opruge, one se skupljaju te je moguće izvući raster iz svjetiljke. To stvara pristup ovjesu unutar svjetiljke. Prilikom izvlačenja, raster je potrebno odvojiti od uzemljenja.
  - 4) Pridržavati svjetiljku dok se odvrću vijci ovjesa jer kada zadnji ovjes popusti, svjetiljka ispada iz stropa.
  - 5) Odvojiti napojni kabel od kleme pritiskom na gripere kleme te izvlačenjem žica.
  - 6) Skinuti difuzor s led modula povlačenjem jedne strane difuzora dok se ne oslobodi od držača LED modula (push-fixeva). Difuzor pažljivo staviti na stranu da se ne ošteti.
  - 7) Odvojiti žicu koja je spojena na svaki LED modul i driver pritiskom na griper žice na LED modulu/driveru tankim predmetom.
  - 8) Odvrnite matice i/ili vijke koji nose driver.
  - 9) Laganim pritiskom na krilca držača LED modula (push-fix), te njihovim skupljanjem, utisnite push-fix kroz rupu na nosaču te ga tako izbacite van. Učinite tako za sve push-fixeve i oslobodit ćete LED modul.
  - 10) Spojiti sve komponente nazad u svjetiljku da bi svjetiljka ispravno funkcionirala.
  - 11) Vratiti sklopku u radno stanje kako bi doveli napajanje do svjetiljke.
- 

## Instructions for dismantling the light source and pre-connected device

### Applicable to: USP

- 1) Turn off the switch so that the lamp is not under voltage during disassembly.
- 2) Carefully pull the aluminum grid so that it pops up to the part where its support springs are visible.
- 3) By pressing on the springs, they contract and it is possible to pull the grid out of the lamp. This creates access to the suspension inside the lamp. When pulling out, it is necessary to separate the grid from the grounding.
- 4) Hold the lamp while unscrewing the suspension screws because when the last suspension loosens, the lamp falls out of the ceiling
- 5) Disconnect the power cable from the terminal by pressing the grippers of the terminal and pulling out the wires.
- 6) Remove the diffuser from the led module by pulling one side of the diffuser until it is released from the LED module holder (push-fixes). Carefully put the diffuser aside to avoid damage.
- 7) Disconnect the wire that is connected to each LED module and driver by pressing the wire gripper on the LED module/driver with a thin object.
- 8) Unscrew the nuts and/or screws holding the driver.
- 9) By gently pressing the wings of the LED module holder (push-fix), and by pulling them together, push the push-fix through the hole on the support and thus eject it. Do this for all push-fixes and you will free the LED module
- 10) Connect all components back to the lamp to make the lamp work properly.
- 11) Return the switch to the working state to supply the power to the lamp.