

## **Uputstva za demontažu izvora svjetlosti i predspojene naprave**

### **Primjenjivo na:** PRIME

- 1) Izbaciti sklopku iz funkcije kako svjetiljka ne bi bila pod naponom prilikom demontaže.
  - 2) Skinuti bočne stranice i difuzor
  - 3) U slučaju da postoji nosač LED modula, odvojite nosač/nosače LED-a iz svjetiljke ili s blende koristeći osnovne kućanske alate. Nosače koji su pričvršćeni magnetom ili oprugom lagano uhvatiti na jednu stranu te povući prema gore dok se nosač ne odvoji od svjetiljke.
  - 4) Odvojiti napojni kabel od kleme pritiskom na gripere kleme te izvlačenjem žica.
  - 5) Odvojiti žicu koja je spojena na svaki LED modul i driver pritiskom na griper žice na LED modulu/driveru tankim predmetom.
  - 6) Odvrnite maticе i/ili vijke koji nose driver.
  - 7) Laganim pritiskom na krilca držača LED modula (push-fix), te njihovim skupljanjem, utisnite push-fix kroz rupu na nosaču te ga tako izbacite van. Učinite tako za sve push-fixeve i oslobođite ćete LED modul. Ako je LED modul vijcima pričvršćen na svjetiljku, laganim odvrtanjem izvadite vijke te tako oslobođite LED modul.
  - 8) Spojiti sve komponente nazad u svjetiljku da bi svjetiljka ispravno funkcionirala. U slučaju da se moduli spajaju na svjetiljku vijcima, potrebno je biti izrazito oprezan kako ne bi došlo do pucanja LED modula.
  - 9) Vratiti sklopku u radno stanje kako bi doveli napajanje do svjetiljke.
- 

## **Instructions for dismantling the light source and pre-connected device**

### **Applicable to:** PRIME

- 1) Turn off the switch so that the lamp is not under voltage during disassembly.
- 2) Remove both sides, then diffuser from the top of the lamp.
- 3) In case there is an LED module support, separate the LED support(s) from the lamp using basic household tools. Lightly grab the supports that are attached by a magnet or a spring on one side and pull upwards until the support is separated from the lamp.
- 4) Disconnect the power cable from the terminal by pressing the grippers of the terminal and pulling out the wires
- 5) Disconnect the wire that is connected to each LED module and driver by pressing the wire gripper on the LED module/driver with a thin object.
- 6) Unscrew the nuts and/or screws holding the driver.
- 7) By gently pressing the wings of the LED module holder (push-fix), and by pulling them together, push the push-fix through the hole on the support and thus eject it. Do this for all push-fixes and you will free the LED module
- 8) Connect all components back to the lamp to make the lamp work properly.
- 9) Return the switch to the working state to supply the power to the lamp.