

Uputstva za demontažu izvora svjetlosti i predspojene naprave

Primjenjivo na: Bolty LA

- 1) Izbaciti sklopku iz funkcije kako svjetiljka ne bi bila pod naponom prilikom demontaže.
 - 2) Skinite difuzor/blendu s vrha svjetiljke. Lagano ga odvojite tankim odvijačem od profila i pažljivo ga odložite sa strane kako biste spriječili pucanje. Ukoliko postoje, odspojite konektore žica koji povezuju LED module sa driverom.
 - 3) Odvojiti napojni kabel od kleme pritiskom na gripere kleme te izvlačenjem žica.
 - 4) Odvojite nosač/nosače LED-a sa blende na način da prvo odvrnemo matice kojima su nosači pričvršćeni na blendu, te zatim vrlo pažljivo povlačimo i odvajamo nosač od blende kako bi se plastični odsjajnik sa prednje strane blende odvojio. Pripaziti da ne dođe do pucanja plastičnog odsjajnika.
 - 5) Odvojiti žicu koja je spojena na svaki LED modul i driver pritiskom na griper žice na LED modulu/driveru tankim predmetom.
 - 6) Odvrnite matice i/ili vijke koji nose driver.
 - 7) Laganim odvrtanjem vijaka sa LED modula ćemo isti osloboditi.
 - 8) Spojiti sve komponente nazad u svjetiljku da bi svjetiljka ispravno funkcionirala. U slučaju da se moduli spajaju na svjetiljku vijcima, potrebno je biti izrazito oprezan kako ne bi došlo do pucanja LED modula.
 - 9) Vratiti sklopku u radno stanje kako bi doveli napajanje do svjetiljke.
-

Instructions for dismantling the light source and pre-connected device

Applicable to: Bolty LA

- 1) Turn off the switch so that the lamp is not under voltage during disassembly.
- 2) Remove the diffuser/cover from the top of the luminaire. Gently separate it from the profile using a thin screwdriver and carefully set it aside to prevent cracking. If present, disconnect the wire connectors that connect the LED modules to the driver.
- 3) Disconnect the power cable from the terminal by pressing the grippers of the terminal and pulling out the wires.
- 4) Remove the LED holder(s) from the cover by first unscrewing the nuts that secure the holders to the cover. Then carefully pull and separate the holder from the cover so that the plastic reflector on the front side of the cover is released. Take care not to crack the plastic reflector.
- 5) Disconnect the wire that is connected to each LED module and driver by pressing the wire gripper on the LED module/driver with a thin object.
- 6) Unscrew the nuts and/or screws holding the driver.
- 7) Carefully loosen the screws securing the LED module to release it. Connect all components back to the lamp to make the lamp work properly.
- 8) Reassemble all components back into the luminaire to ensure proper operation. If the modules are fastened to the luminaire with screws, exercise extreme caution to avoid cracking the LED modules.
- 9) Return the switch to the working state to supply the power to the lamp.