

Uputstva za demontažu izvora svjetlosti i predspojene naprave

Primjenjivo na: Leduina

- 1) Izbaciti sklopku iz funkcije kako svjetiljka ne bi bila pod naponom prilikom demontaže.
 - 2) Otpojiti IP65 brzi konektor s vanjske strane svjetiljke kako bi odvojili napojni kabel od svjetiljke.
 - 3) Odvrnuti vijke s maske kako bi ju mogli ukloniti.
 - 4) Ako je nosač LED modula za svjetiljku pričvršćen vijcima, odvrnuti vijke te potom izvaditi nosač LED modula iz svjetiljke. Ako je nosač pritisnut limenim stezačima, nosač osloboditi tako da stezače odvojimo rukama od nosača te potom izvadimo nosač iz svjetiljke.
 - 5) Odvojiti žice koje su spojene na driver pritiskom na griper žice na driveru tankim predmetom.
 - 6) Leću koja se nalazi preko LED modula ukloniti laganim klizanjem leće dok ju ne izvadimo.
 - 7) Odvojiti žicu koja je spojena na LED module pritiskom na griper žice na LED modulu tankim predmetom.
 - 8) Odvrnite matice i/ili vijke koji nose driver.
 - 9) Laganim pritiskom na krilca držača LED modula (push-fix), te njihovim skupljanjem, utisnite push-fix kroz rupu na nosaču te ga tako izbacite van. Učinite tako za sve push-fixeve i oslobodit ćete LED modul.
 - 10) Spojiti sve komponente nazad u svjetiljku da bi svjetiljka ispravno funkcionirala.
 - 11) Vratiti sklopku u radno stanje kako bi doveli napajanje do svjetiljke.
-

Instructions for dismantling the light source and pre-connected device

Applicable to: Leduina

- 1) Turn off the switch so that the lamp is not under voltage during disassembly.
- 2) Disconnect the IP65 quick connector on the outside of the lamp to separate the power cable from the lamp.
- 3) Unscrew the screws from the mask to remove it.
- 4) If the LED module support for the lamp is fixed with screws, unscrew the screws and then remove the LED module support from the lamp. If the bracket is pressed with sheet metal clamps, release the bracket by separating the clamps from the bracket with your hands and then remove the bracket from the lamp.
- 5) Disconnect the wires that are connected to the driver by pressing on the gripper of the wires on the driver with a thin object.
- 6) Remove the lens located over the LED module by gently sliding the lens until it is removed.
- 7) Disconnect the wire connected to the LED module by pressing the wire gripper on the LED module with a thin object.
- 8) Unscrew the nuts and/or screws holding the driver.
- 9) By gently pressing the wings of the LED module holder (push-fix), and by pulling them together, push the push-fix through the hole on the support and thus eject it. Do this for all push-fixes and you will free the LED module.
- 10) Connect all components back to the lamp to make the lamp work properly.
- 11) Return the switch to the working state to supply the power to the lamp.