

Uputstva za demontažu izvora svjetlosti i predspojene naprave

Primjenjivo na: Planet wall, Line

- 1) Izbaciti sklopku iz funkcije kako svjetiljka ne bi bila pod naponom prilikom demontaže.
 - 2) Skinuti difuzor s gornje strane svjetiljke. Lagano ga odići tankim odvijačem te pažljivo odložiti da ne bi došlo do pucanja.
 - 3) Odvinuti vijke koji drže nosač s unutarnje strane svjetiljke. Prilikom uklanjanja nosača iz svjetiljke, pritiskom na griper kleme osloboditi kabel vanjskog napajanja koji je spojen na klemu.
 - 4) Odvojiti žicu koja je spojena na svaki LED modul i driver pritiskom na griper žice na LED modulu/driveru tankim predmetom.
 - 5) Nosač LED-a vratiti u svjetiljku do ponovne montaže svjetiljke.
 - 6) Odvrnite matice i/ili vijke koji nose driver.
 - 7) Laganim pritiskom na krilca držača LED modula (push-fix), te njihovim skupljanjem, utisnite push-fix kroz rupu na nosaču te ga tako izbacite van. Učinite tako za sve push-fixeve i oslobodit ćete LED modul.
 - 8) Spojiti sve komponente nazad u svjetiljku da bi svjetiljka ispravno funkcionirala.
 - 9) Vratiti sklopku u radno stanje kako bi doveli napajanje do svjetiljke.
-

Instructions for dismantling the light source and pre-connected device

Applicable to: Planet wall, Line

- 1) Turn off the switch so that the lamp is not under voltage during disassembly.
- 2) Remove the diffuser from the top of the lamp. Gently pry it off with a thin screwdriver and carefully set it aside to prevent it from cracking.
- 3) Unscrew the screws that hold the support on the inside of the lamp. When removing the support from the lamp, press the terminal gripper to release the external power cable connected to the terminal.
- 4) Disconnect the wire that is connected to each LED module and driver by pressing the wire gripper on the LED module/driver with a thin object.
- 5) Return the LED holder to the lamp until the lamp is reassembled
- 6) Unscrew the nuts and/or screws holding the driver.
- 7) By gently pressing the wings of the LED module holder (push-fix), and by pulling them together, push the push-fix through the hole on the support and thus eject it. Do this for all push-fixes and you will free the LED module
- 8) Connect all components back to the lamp to make the lamp work properly.
- 9) Return the switch to the working state to supply the power to the lamp.