

Uputstva za demontažu izvora svjetlosti i predspojene naprave

Primjenjivo na: Mirro

- 1) Izbaciti sklopku iz funkcije kako svjetiljka ne bi bila pod naponom prilikom demontaže.
 - 2) Skinuti bočni poklopac laganim povlačenjem.
 - 3) Skinuti difuzor laganim povlačenjem prema gore kako bi se difuzor oslobodio kanala u kojem se nalazi. Odložiti difuzor pažljivo kako ne bi došlo do njegovog pucanja.
 - 4) Nosač LED-a, koji je oprugama pričvršćen s profilom, povući prema gore (kao i difuzor) kako bi se opruga oslobodila od kanala u kojem se nalazi.
 - 5) Odvojiti napojni kabel od kleme pritiskom na gripere kleme te izvlačenjem žica.
 - 6) Odvojiti žicu koja je spojena na svaki LED modul i driver pritiskom na griper žice na LED modulu/driveru tankim predmetom.
 - 7) Odvrnite matice i/ili vijke koji nose driver.
 - 8) Laganim pritiskom na krilca držača LED modula (push-fix), te njihovim skupljanjem, utisnite push-fix kroz rupu na nosaču te ga tako izbacite van. Učinite tako za sve push-fixeve i oslobodit ćete LED modul.
 - 9) Spojiti sve komponente nazad u svjetiljku da bi svjetiljka ispravno funkcionirala.
 - 10) Vratiti sklopku u radno stanje kako bi doveli napajanje do svjetiljke.
-

Instructions for dismantling the light source and pre-connected device

Applicable to: Mirro

- 1) Turn off the switch so that the lamp is not under voltage during disassembly.
- 2) Remove the side cover by gently pulling on it.
- 3) Remove the diffuser by gently pulling it upwards to free the diffuser from the channel in which it is located. Dispose of the diffuser carefully so that it does not break.
- 4) Pull the LED support, which is attached to the profile with springs, upwards (as well as the diffuser) in order to release the spring from the channel in which it is located.
- 5) Disconnect the power cable from the terminal by pressing the grippers of the terminal and pulling out the wires.
- 6) Disconnect the wire that is connected to each LED module and driver by pressing the wire gripper on the LED module/driver with a thin object.
- 7) Unscrew the nuts and/or screws holding the driver.
- 8) By gently pressing the wings of the LED module holder (push-fix), and by pulling them together, push the push-fix through the hole on the support and thus eject it. Do this for all push-fixes and you will free the LED module
- 9) Connect all components back to the lamp to make the lamp work properly.
- 10) Return the switch to the working state to supply the power to the lamp.