

Uputstva za demontažu izvora svjetlosti i predspojene naprave

Primjenjivo na: Lypso, Bolty, Bolty L, Slash, Stripe, Stripe L, Soft, Thin, Bolin, Trini 3ph, Bolin System

- 1) Izbaciti sklopku iz funkcije kako svjetiljka ne bi bila pod naponom prilikom demontaže.
 - 2) Remove the diffuser from the lamp by inserting a thin screwdriver or similar object between the side cover and the diffuser/shroud, and gently pulling towards you.
 - 3) U slučaju da postoji nosač LED modula, odvojite nosač/nosače LED-a iz svjetiljke ili s blende koristeći osnovne kućanske alate. Nosače koji su pričvršćeni magnetom ili oprugom lagano uhvatiti na jednu stranu te povući prema gore dok se nosač ne odvoji od svjetiljke.
 - 4) Odvojiti napojni kabel od kleme pritiskom na gripere kleme te izvlačenjem žica.
 - 5) Odvojiti žicu koja je spojena na svaki LED modul i driver pritiskom na griper žice na LED modulu/driveru tankim predmetom.
 - 6) Odvrtite matice i/ili vijke koji nose driver.
 - 7) Laganim pritiskom na krilca držača LED modula (push-fix), te njihovim skupljanjem, utisnite push-fix kroz rupu na nosaču te ga tako izbacite van. Učinite tako za sve push-fixeve i oslobodit ćete LED modul. Ako je LED modul vijcima pričvršćen na svjetiljku, laganim odvrtanjem izvadite vijke te tako oslobodite LED modul.
 - 8) Spojiti sve komponente nazad u svjetiljku da bi svjetiljka ispravno funkcionirala. U slučaju da se moduli spajaju na svjetiljku vijcima, potrebno je biti izrazito oprezan kako ne bi došlo do pucanja LED modula.
 - 9) Vratiti sklopku u radno stanje kako bi doveli napajanje do svjetiljke.
-

Instructions for dismantling the light source and pre-connected device

Applicable to: Lypso, Bolty, Bolty L, Slash, Stripe, Stripe L, Soft, Thin, Bolin, Trini 3ph, Bolin System

- 1) Turn off the switch so that the lamp is not under voltage during disassembly.
- 2) Remove the diffuser from the top of the lamp. Gently pry it off with a thin screwdriver and carefully set it aside to prevent it from cracking.
- 3) In case there is an LED module support, separate the LED support(s) from the lamp using basic household tools. Lightly grab the supports that are attached by a magnet or a spring on one side and pull upwards until the support is separated from the lamp.
- 4) Disconnect the power cable from the terminal by pressing the grippers of the terminal and pulling out the wires
- 5) Disconnect the wire that is connected to each LED module and driver by pressing the wire gripper on the LED module/driver with a thin object.
- 6) Unscrew the nuts and/or screws holding the driver.
- 7) By gently pressing the wings of the LED module holder (push-fix), and by pulling them together, push the push-fix through the hole on the support and thus eject it. Do this for all push-fixes and you will free the LED module
- 8) Connect all components back to the lamp to make the lamp work properly.
- 9) Return the switch to the working state to supply the power to the lamp.p